



NCFI POLYURETHANES
 Div. of BMC
 P. O. Box 1528 • Mount Airy, NC 27030
 800.346.8229 www.NCFI.com

INSULATION FACT SHEET

Doc 136

SPRAY INSULATION SYSTEM 12-002

This is NCFI Sprayed-in-Place Polyurethane Foam Insulation System 12-002 for use in NCFI SEALITE™ Residential Insulation Systems.

All insulation systems provide R-Value, the resistance to heat flow by thermal diffusion. SEALITE insulation not only provides R-value but also is an excellent air barrier and noise barrier. **This gives you far greater value for your insulation dollar than conventional insulations such as glass fiber or cellulose.**

R* Values	
Thickness	R-Value (°F·hr·ft² / Btu)
3.5"	13
* Note: As with all insulating materials, the R-value will vary with age and use conditions.	

Read This Before you Buy

What you should know about R-values

The chart shows the R-value of this insulation. R means resistance to heat flow. The higher the R-value, the greater the insulating power. Compare insulation R-values before you buy. There are other factors to consider. The amount of insulation you need depends mainly on the climate you live in. Also, your fuel savings from insulation will depend upon the climate, the type and size of your house, the amount of insulation already in your house, and your fuel use patterns and family size. If you buy too much insulation, it will cost you more than what you'll save on fuel. To get the marked R-value, it is essential that this insulation be installed properly.